


The Instruction of Remote BF-305



1. Select the Channel for Programming:

Press "CHANNEL+" or "CHANNEL-" to choose the channel until the LED bright on the channel you want.

2. Programming this channel on the Motor or Receiver:

to have the motor or receiver under the programming state (operating according to the instructions of the motor or receiver, i.e. keep pressing SETTING key on the motor head or receiver until they respond KA KA or Di--Di--)

3. Then press the CONFIRM key on the remote

(do it in 3 seconds after the motor under the programming state), the motor jogs KA KA or the receiver sounds Di Di Di Di to confirm the programming succeed.

FIY:

The group channel will be recorded on the motor automatically when the single channel has been programmed on the motor.